Product datasheet

Perforated sleeve for chemical anchor





Function: The perforation sleeve is used together with the chemical anchor for attachment to hollow block. The sleeve causes the chemical anchor to form a body around the part to be fixed to the hole.



Installation instructions: Drill holes in the hollow block as instructed and push into the perforation sleeve in the hole. Fill the entire perforated sleeve with chemical anchor. Now press in and screw the fastener to the bottom of the perforated sleeve. Allow the compound to cure before loading.



D	L	Art.no	E-number	Quantity	Pack.	MB
12	50	84714		10	Packaging	20
16	85	84715		10	Packaging	10
16	130	84720		10	Packaging	10
20	85	84716		10	Packaging	6



1/1

CUSTOMER SERVICE

Tel. 033-23 03 03 Email: vsb@vsbyggskruv.se Website: vsbyggskruv.se

ADDRESS

Västsvensk Byggskruv AB Vävlagargatan 7 507 30 Brämhult Sweden

