

Product datasheet

Pressure distribution washer




Function: The pressure distribution washer is used for installing frame sockets to porous and uneven surfaces.

Installation instructions: Secure the pressure distribution washer to the bottom plate of the frame socket, and then fit the frame socket as instructed.

D	D1	M	Art.no	E-number	Quantity	Pack.	MB
8	44	3.7	44040		25	Packaging	12
8	44	3.7	SB44040		6	Pack	10

NOTE: Packs are only sold in multiples of ten.



Produkten bedömd i
SundaHus Miljödata



CUSTOMER SERVICE

Tel. 033-23 03 03
Email: vsb@vsbyggskruv.se
Website: vsbyggskruv.se

ADDRESS

Västsvensk Byggskruv AB
Vävlagargatan 7
507 30 Brämhult
Sweden

